

FOOTBOARD EXTENSIONS | CAL KING ASSEMBLY INSTRUCTIONS

Parts List:

2 Footboard Extensions | 6 Lock Nuts | 6 Carriage Bolts | 6 Washers

Step 1

Align Footboard extension with the three corresponding holes at the foot of the bed frame as shown in figure 1.

Step 2

Thread Carriage bolts through each hole towards the outside of the frame. Pair each bolt with a washer and lock nut. Place the washers on the end of the bolt and hand-tighten each lock nut.

Step 3

Repeat this step for the opposing foot of the bed frame.

Step 4

Using the included wrench, tighten the nuts and bolts the rest of the way.

Note:

Footboard extensions are meant for use with Structures™ bed frames only.
Fits model **ST6633BF** and **ST6633GL**



FOOTBOARD EXTENSION

