

QUEEN MODI PLATE

ASSEMBLY INSTRUCTIONS

Parts List:

2 Modi Plates | 4 Lock Nuts | 4 Bolts



QUEEN MODI PLATE

Step 1

Place assembled bed frame in front of headboard and position modi plate to determine which slots will line up with headboard brackets and headboard. Use provided lock nuts and bolts to attach modi plates to headboard brackets as shown in figure 1.

Step 2

Bolt modi plates to headboard. (Nuts and bolts to attach modi plates to headboard are not included in this kit.)

