

# BOLT ON TO HOOK IN CONVERTER ASSEMBLY INSTRUCTIONS

## Parts List:

2 Bed Hooks | 4 Hex Nuts | 4 Lock Washers | 4 Bolts

### Step 1

Insert one bed hook (hooks pointing downward) into headboard leg and tap hook securely into place.

### Step 2

Determine which set of slots in bed hook, frame should be bolted to, so that headboard legs are slightly suspended above the floor.

### Step 3

Remove bed hook from headboard and loosely attach both bed hooks to frame, through slots determined previously, using bolts, lock washers and nuts provided. See figure 1.

### Step 4

Place headboard on hooks and tighten bolts securely. See figure 2.

